

INSTRUCTIONS MANUAL for ANTIMIST PAD FOR MIRROR

(References ABCI6011EX - ABCI4050EX - ABCI5580EX -ABC4898)

- ✓ Clean the back mirror with dry cloth or soaked in alcohol. Dry leave.
- ✓ Center your antimist pad front demister paper against the tain mirror.
- ✓ Set 2 angles on film mirror thanks to his face adhesive (Figure 1).
- ✓ Side opposite of such adhesives, launching the paper in the tie between the film and the mirror (Figure 2).
- ✓ Contacting the adhesive and covered with the back of the mirror by applying pressure (masking) over the entire surface.
- ✓ Off the previous two angles and completely remove the protective paper by pressing the film to prevent the formation of air bubbles (Figure 3).

